	TE-PUFPLUS Hi-Vol PAH Air Sample Data Form
Sample Information	Full Site Name: Portage Hay 12 Site Abbreviation PtG - A - 3 Deployment No Clean Batch PUF Plug No Clean Batch Filter No
Field Deployment and Recovery	Field Deployment Technician Name Selection Setup Date/Time 4/16/21 9:35 Sample Run Date 6/18/22 Flow Conditions should be STD. Flow Rate should be 225 liters/min. Once all necessary fields in Timer screen have been set, 3 things should happen: Green power light should start to blink; Timer countdown should start indicating when sampling run will commence; Status on main screen should change to "Waiting". Field Recovery Technician Name Recovery Date/Time 4/19/21 13:30 Qstd Avg Flow (liters/min) 2.5 Actual Start Date/Time 4/19/21 0:40 Qstd Avg Flow (liters/min) 2.5 Actual Storp Date/Time 4/19/21 0:40 Qstd Volume (m³) 3.23.31 Tamb Avg (°C) Elapsed Time (HH:MM) 2.43.40 Pamb Avg (mmHg) Flags? Expected flags: Completed, Qstd No unexpected flags [KMH 5/20/21] Sample Status: VALID VOID (circle one) Site Observations Run Day Temperatures: High S Low 3 Source: W44ther Charnel Run Day Wind/Wind Direction: Substance Substance
Maintenance	Check all that apply. All weekly checks performed by Scott Keller [KMH 6/7/21] Weekly Checks: